

TECHLIFT M4

To activate the reset, turn the knob clockwise (see picture 1) and hold for about 10 sec, the lift starts and goes slowly downwards (**lamp fault lights up NOTE with this downward movement, crushing protection is not activated, take extra care and make sure that no obstacles are found under the platform**). Hold the knob down during the entire lift movement and release it only when the light (**fault** see picture 2) has gone out and the lift is at the bottom.



picture 1



picture 2

TECHLINE

Manufacturer TECH LINE Kyrkbacken 2 SE- 507 90 Brämhult

Tel: + 46 (0) 709 837972 E-Post: stefan@htu-center.se Webb: www.techline.nu